

STARTUP



1) How to connect the MediaVr (server).



- 1** The MediaVr is a rip NAS (server).
- 2** Connect your MediaVr with your network/ router or switch (preferred Cat 6).
- 3** Connect the power supply of the server.
- 4** Press the start button.

To access the web server of your MediaVr click <http://mediavr/ripstatus.php>



2) How to connect the MediaV (player).

5



6



7



8



5

The MediaV is a media player.


6

Connect your MediaV with your network/ router or switch and connect your TV and your MediaV with an HDMI cable. Turn on your TV.

7

Put batteries into the remote control. Connect the power supply of the MediaV.

8

Press the button power  on the remote or on the MediaV. Enjoy!

To access the web server of your MediaV click <http://visonos:8080>